

## INSTALLATION, OPERATION AND MAINTENANCE MANUAL

## Angle Seat Valve with Spring Return Pneumatic Actuator



## GENEBRE reference: 5060 - 5060N

GENEBRE S.A.

# GENEBRE

## Installation, Operation and Maintenance Instructions

1) Breakdown drawing	3
1.1) List of components:	3
2) Storage	1
3) Installation Instructions	5
3.1) Preparation	5
3.3) Pneumatic Connection	3
4) Operating Instructions	7
4.1) Use	7
4.2) Special Conditions	7
5) Maintenance Instructions	7
6) Repairing Instructions	3
6.1) Dismantling	3
6.2) Changing the Seat	3
6.3) Changing the Gasket	)
7) Hygiene and Safety:1	1



## 1) Breakdown drawing.



#### 1.1) List of components:

N٥	Name	Material	Surface Treatment	Spare Part Code
1*	Indicator Protector	Plastic		C5060
2	O'ring	NBR		
3	Indicator	Nylon		
4	Spring	Steel 65Mn		
5	Nut	Aluminum		
6	Actuator Body	Stainless Steel CF8 (304)	Shot blasting	
7	Piston	Aluminum Alloy		
8*	Piston Ring	FKM		R5060
9	O'ring	NBR		
10	Washer	Stainless Steel AISI 304		



Bearing	Aluminum Alloy		
Cover	Stainless Steel AISI 304		
O'ring	NBR		R5060
Check Ring	Stainless Steel AISI 304		
Connection	Stainless Steel CF8M (316)		
Body Seal	PTFE		R5060
Stem	Stainless Steel AISI 316		
Seat Support	Stainless Steel CF8M (316)		
Seat	PTFE		R5060
Nut	Stainless Steel AISI 316		
Y - Ring	FKM		
Washer	Stainless Steel AISI 304		
Spring	Stainless Steel AISI 304		
Washer	Stainless Steel AISI 304		
Stem Packing	PTFE + Carbon		E5060
Stem Packing	PTFE		E5060
Stem Packing	PTFE + Carbon		E5060
Valve Body	Stainless Steel 1.4408 (CF8M)	Shot blasting	
	BearingCoverO'ringCheck RingConnectionBody SealStemStemSeat SupportSeat SupportSeatNutY - RingWasherSpringWasherStem PackingStem PackingStem PackingStem PackingStem PackingValve Body	BearingAluminum AlloyCoverStainless Steel AISI 304O'ringNBRCheck RingStainless Steel AISI 304ConnectionStainless Steel CF8M (316)Body SealPTFEStemStainless Steel AISI 316Seat SupportStainless Steel CF8M (316)SeatPTFENutStainless Steel AISI 316Y - RingFKMWasherStainless Steel AISI 304SpringStainless Steel AISI 304Stem PackingPTFE + CarbonStem PackingPTFE + CarbonValve BodyStainless Steel 1.4408 (CF8M)	BearingAluminum AlloyCoverStainless Steel AISI 304O'ringNBRCheck RingStainless Steel AISI 304Check RingStainless Steel CF8M (316)Body SealPTFEBody SealPTFEStemStainless Steel AISI 316StemStainless Steel CF8M (316)SeatPTFENutStainless Steel AISI 316Y - RingFKMWasherStainless Steel AISI 304SpringStainless Steel AISI 304Stem PackingPTFE + CarbonStem PackingPTFE + CarbonValve BodyStainless Steel 1.4408 (CF8M)Shot blasting

\* Available spare parts

## 2) Storage

During storage it is recommended to keep the packaging on to avoid bumps o excessive dirt (the packaging should not be removed until the item is to be installed). Store in a dry clean environment whenever possible.

## ♦

Transportation and storage of these items must be done in its original packaging!

#### VISUAL INSPECTION

Check that the equipment has not been damaged during transportation, unloading and settling.

#### **MECHANICAL VERIFICATION**

Check that all moveable parts on the equipment, as well as the screws and other elements do their job.

## 8

Should any error be detected during this reception procedure, contact GENEBRE immediately so as to resolve whose responsibility it is and to set the equipment back to the correct operating state!



#### **IMPORTANT NOTE:**

Before installing and/or handling these pneumatic elements, READ CAREFULLY these instructions and OBSERVE all the information contained therein. Should you not understand any piece of information, please <u>contact GENEBRE, S.A.</u>

Responsibility for the safe use of this equipment belongs to the user, as established in these instructions, as well as in the technical documentation specific to the supplied equipment.

### 3) Installation Instructions

#### 3.1) Preparation

Remove any remains of packaging from the valve.

There might be serious problems caused by valves installed in a dirty pipe.

Make sure the valve is free of dirt, welding particles, etc. before installation, since the valve might suffer irreparable damage when the equipment is turned on  $\rightarrow$  prepare a clean working area.

Plan enough space for future maintenance operations.

#### 3.2) Valve's Installation

Make sure the pipe and the thread on the pipe are clean and are compatible (Thread type). Apply the proper sealer on the pipe threads and screw the valve in carefully so as not to tighten the conical threads in excess.

Do not use the valve actuator as a crowbar to thread the valve to the pipe.

To tighten the valve to the pipe, it is recommended to use a flat wrench or a monkey wrench, applying strength only on the hexagonal area on the ends of the valve. It is recommended to apply less than 30 Nm of strength.

The design of this type of valve has only one mounting position on the pipe, which is indicated by an arrow engraved on the body of the valve to know which direction the fluid must flow.





Simple Effect Actuator (Spring Return) Normal Closed (N.C.)

It is recommended that, whenever possible, the valve is installed in a horizontal position with the actuator facing up.

The valves should not stand burdens or efforts that should be carried by the pipe, which is why it is recommended to have a good alignment and parallelism of the pipe.

We recommend the use of filters on the pipes to extend the lifespan of the valves.

#### 3.3) Pneumatic Connection

The orifice for air feeding to the actuator is G 1/8".

**IMPORTANT:** The supply air to use must be **CLEAN and DRY**. Respect the minimum and maximum supply pressure (3 – 8 bar)





## 4) Operating Instructions

#### 4.1) Use

Before turning on the equipment, you must always take into account the Technical Specifications and never exceed the values of the Feeding Limits of power and air.

Never touch the valve and/or pipes that are in contact with the surrounding fluid when the process is active, since burns may occur.

- Operation medium: Dry or lubricated air, or inert non-corrosive gas.
- Air supply: 3 Bar (45 PSIG) to 8 Bar (120 PSIG) maximum.
- Working temperature: Standard -10°C to +60°C.
- Working environment: Suitable for internal use or outdoors applications.

#### 4.2) Special Conditions

• The operation of the actuator in extreme temperature conditions exceeding the design limits may damage internal and external parts, and it might be potentially hazardous for the operating or maintenance personnel.

• The operation of the actuator in extreme pressure conditions exceeding the design limits may cause a malfunction of the actuator and the spontaneous breakage of parts and, therefore, might be potentially hazardous for the operating or maintenance personnel.

• Note: Do not dismantle the actuator under any circumstances when it is under supply pressure.

### 5) Maintenance Instructions

This **product** does not require any kind of maintenance.

If any internal part has been damaged, contact Genebre, S.A. to assess the possibility of repair.



## 6) Repairing Instructions

Genebre, S.A. is not held responsible for the incorrect handling of the equipment or its parts.

Before repairing begins, disconnect the actuator pneumatically and electrically.



#### 6.1) Dismantling

Prepare a clean working area and the proper tools for mechanical tasks.



Before removing the valve from the pipe for cleaning or substitution, make sure the line has been closed and depressurized, since the wrong handling might cause a serious accident as well as serious damage to the equipment



• BEFORE PERFORMING ANY MAINTENANCE OPERATION ON THE ACTUATORS, IT IS ESSENTIAL THAT THEY ARE NOT UNDER PRESSURE AND FREE OF ANY ACCESSORIES.

• FOR YOUR OWN SAFETY IT IS NECESSARY TO CHECK THAT THE UNIT IS IN FAIL POSITION (EXTENDED AND UNCOMPRESSED SPRING) BEFORE DISMANTLING A SIMPLE EFFECT ACTUATOR (SPRING RETURN).

To perform the operation it is **NOT** necessary to remove the valve from the installation.

#### 6.2) Changing the Seat

Loosen and remove the piece that joins to the valve (part 15) together with the actuator. Be careful not to damage the surface of the valve.

Once the set has been removed, remove the nut that attaches to the seat (part 20) and remove the seat from its enclosure. Place the new seat (part 19) and tighten up with the nut (part 20)



Clean the seat area of the body of the valve before replacing the actuator set and verifying its state. Should this area be damaged by the excessive use of the valve or by the effect of the fluid that flows through the pipe, the body should be completely replaced.

Next, remove the gasket from the body (part.16) and replace it.

#### **Reassembling:**

Screw in the whole actuator set with the piece that attaches it to the valve. If possible, perform this operation feeding air to the actuator to avoid friction between the seat and the base of the body when screwing in the whole set, since the configuration of the valve is N.C (normal closed).

Before turning on the installation, check the proper operation of the equipment with a dry run (no fluid).

#### 6.3) Changing the Stem Packing

The piece that joins the valve and the actuator (part 15) has a hole on the side that would indicate whether there is a leak through the shaft gasket. Should a fluid leak through this hole be detected, the Stem Packing (part 25,29 and 31) should be replaced immediately.

Loosen and remove the piece that joins to the valve (part 15) together with the actuator. Be careful not to damage the surface of the valve.

Since it is necessary to dismantle the actuator to change the shaft gasket, it is recommended to thoroughly review all the internal parts and, should any wear on the parts be detected, proceed to replace them too.



The dismantling of the actuator must be performed with extreme care, since removing the seeger ring might eject the piston and might cause a serious accident as well as serious damage to the equipment

## GENEBRE

Genebre Building. Av. de Joan Carles I, 46-48 08908 L'Hospitalet de Llobregat. Barcelona (Spain) genebre@genebre.es - www.genebre.es

With the help of a small press or a bench screw, apply some pressure between the planes shown in the following figure to slightly compress the spring and then be able to remove the seeger ring (part 14) that holds the piston. Slowly loosen the pressure between these two planes until it is completely released from the pressure of the spring.



Then remove the whole set from inside the body of the actuator (part 6).

Unscrew the nut that holds the seat (part 20) and also remove the seat assembly with the piece where it is enclosed (part 18 and 19), push the shaft upwards and the whole set made up of the shaft (part 17), the piston (part 7), the nut (part 5) and the indicator (part 3) will come off.

Holding with a wrench from the hexagonal part of the piece that joins to the valve (part 15), unscrew the lid (part 12 base of the actuator or lid).

Remove the spring (part 23) and with the help of a sharp object remove the set made up of the stem packing (part 25, 29 and 31) and the washer (part 24).

Clean all parts of the set before proceeding to reassemble it with the new parts.

#### Reassembling

A.- When it is not necessary to repair the actuator, proceed as follows:

Place the new stem packing (part 25, 29 and 31) as shown in the following figure, inside the piece that joins the valve and the actuator (part 15), using some sort of lubricant to help perform the task:



GENEBRE S.A.

UPDATE NUMBER: 1



Place the washer on top of the gasket (part 24) and then place the spring (part 23). Screw the whole set to the lid or base of the actuator (part 12), and then insert the gasket and piston set through the top.

Place the seat assembly (part 18 and 19) on the end of the gasket and fix it with the nut (part 20).

Verify the presence of the spring (part 4) inside the body of the actuator (part 6) and insert the whole set. It is important to use some sort of lubricant to make the sliding easier.

Once more, with the help of a small press or a bench screw, apply some pressure between the planes shown in the following figure to slightly compress the spring and then be able to place the seeger ring (part 14) which will hold the lid or base of the actuator (part 12). Slowly loosen the pressure between these two planes until you can make sure the seeger is properly placed.



Attach the whole assembly to the body of the valve (part 30) as explained in section 6.2 (Reassembling)

B.- If we want to perform repairs on the actuator

Before proceeding to the assembly, you should check the state of internal parts 8 and 13 for instance, and if necessary, replace them. Then, continue the assembly as instructed in the previous item.

## 7) Hygiene and Safety:

When handling any kind of element, the appropriate safety measures should be taken, and it is recommended to use personal protection elements:

- 1) Use eye protection.
- 2) Use proper gloves and work clothes.
- 3) Use protective footwear.
- 4) Use a helmet.
- 5) Be sure there is running water available.

GENEBRE S.A.