



المرجع: GW01 16 01 00 / GW01 16 01 04

دليل التعليمات  
Instruction manual

محفف الأيدي  
HAND DRYER

**GENWEC®**



يُرجى قراءة التعليمات التالية بعناية وأخذها في الاعتبار قبل إجراء أي عملية.

- لا يمكن تركيب هذا الجهاز وضبطه وصيانته إلا من قبل فني مؤهل.
- كن حذرًا عند إزالة الغطاء البلاستيكي الأمامي لأنه يتم كشف أجزاء نشطة ومتصلة بالكهرباء من الجهاز، ومن ثم يكون هناك خطر محتمل لحدوث صدمة كهربائية.
- يجب فصل التيار الكهربائي من الموصلات الرئيسية قبل إجراء أي معالجة كهربائية.
- يجب تضمين وسائل فصل، ببتباع 3 مم على الأقل بين نقاط التلامس (0.12 بوصة) في أسلاك التثبيت التي تتضمن جميع الأقطاب، وفقًا لقواعد الأسلاك.
- تُعد الأجهزة من نوع GW01 16 01 00 وGW01 16 01 04 هي أجهزة كهربائية عازلة من الفئة الثانية، لذا لا يلزم تأريضها.

تنبيه: لتجنب الخطر الناجم عن إعادة الضبط غير المقصود للقواطع الحراري، يجب عدم تزويد هذا الجهاز بالطاقة من خلال جهاز تبديل خارجي، مثل مؤقت، أو توصيله بدائرة يتم تشغيلها وإيقاف تشغيلها بانتظام بواسطة المرفق.

هذا الجهاز غير مُخصص للاستخدام من قبل الأشخاص (بما في ذلك الأطفال الذين تقل أعمارهم عن 8 سنوات) الذين يعانون من ضعف القدرات البدنية أو الحسية أو العقلية، أو الذين يفتقرون إلى الخبرة والمعرفة، ما لم يتم الإشراف عليهم أو توجيههم بشأن استخدام الجهاز من قبل شخص مسؤول عن سلامتهم.

يجب مراقبة الأطفال لضمان عدم عبثهم بالجهاز.

يجب ألا يعبث الأطفال بالجهاز.

لا تستخدم هذا الجهاز بالقرب من أحواض الاستحمام أو الدش أو الأحواض أو الأوعية الأخرى التي تحتوي على الماء.

في حال تلف سلك الإمداد بالطاقة، يجب استبداله من قبل الشركة المصنعة أو وكيل الخدمة التابع لها أو من قبل أشخاص مؤهلين بنفس الدرجة لتجنب الأخطار.

أثناء عملية التركيب، يجب مراعاة مناطق الحماية وفقًا لمعيار VDE 0100.

لا يُمكن للأطفال إجراء تنظيف وصيانة الجهاز دون إشراف.

طراز "Genwec Condor" عبارة عن مجفف لليدين يتميز بالكفاءة وصغر الحجم والتصميم المبتكر، حيث إن تركيبه (لوحة القاعدة) والقنوات الداخلية والغطاء الأمامي مصنوع من مواد بلاستيكية حرارية عالية الجودة ويتوفر بنوعين من التشطيب وفقًا للرموز التالية:

- غطاء أمامي أبيض من الأكريلونيتريل بوتادين ستيرين (ABS) (GW01 16 01 00)
- غطاء أمامي فضي من الأكريلونيتريل بوتادين ستيرين (ABS) (GW01 16 01 04)

وحدات هذا المجفف عبارة عن أجهزة من الفئة الثانية تعتمد على العزل الكهربائي، ولا يلزم توصيلها بطرف التأسيس في المبنى لأنها تتمتع بعزل كهربائي مزدوج.

يتم تشغيل مجفف اليدين تلقائيًا من خلال دمج مستشعرات الأشعة تحت الحمراء على كلا الجانبين والتي تنشط المحرك والسخان عند تقريب يدي المستخدم.

تعتمد عملية التجفيف على إصدار تيارات هواء متجانسة عالية السرعة تُوجّه عبر فتحات مستطيلة الشكل تقع على جانبي المجفف.

مستوى الضوضاء المنخفض والاستهلاك المحدود للطاقة يجعلان هذه الطرز مجففات فعالة وصديقة للبيئة. وبشكل أكثر تحديداً، يتم إلغاء تنشيط عنصر التسخين تلقائياً إذا كانت درجة حرارة الغرفة أعلى من 25 درجة مئوية، ومن ثم يؤدي هذا إلى توفير الطاقة.

توجد مداخل الهواء بشكل عمودي على جانبي الجهاز.

يتضمن مجفف الأيدي عناصر للتجفيف والنظافة مثل فلتر HEPA ومصباح الأشعة فوق البنفسجية-سي (UVC).


يتم تجميع المياه المتبقية من كل عملية تجفيف في خزان مياه قابل للإزالة موجود أسفل الجهاز.

كما يحتوي المجفف على شاشة معلوماتية في الجزء العلوي بالإضافة إلى شريط من مصابيح LED في الجزء السفلي يشير إلى حالة التشغيل وامتلاء خزان المياه.


باختصار، الميزات الفنية الأكثر صلة بهذه المجموعة من المجففات هي:

- التجفيف السريع والفعال بناءً على مخارج الهواء المتعددة
- الاستهلاك المنخفض للطاقة
- وضع التركيب السريع والسهل
- فلتر HEPA ومصباح الأشعة فوق البنفسجية-سي (UVC) لتعقيم الهواء المزود
- الحد الأقصى لوقت التشغيل المستمر = 25 ثانية (Tsh)
- لوحة معلومات الحالة وإنذار "الخزان الكامل" المرئي/المسموع
- الفصل التلقائي لعنصر التسخين إذا كانت درجة حرارة الغرفة أعلى من 25 درجة مئوية
- مواد بلاستيكية قوية وعالية الجودة

297 مم



164 مم




574 مم

## الخصائص الفنية الرئيسية

المواصفات الكهربائية	مواصفات السوائل	المواصفات الميكانيكية
مصدر الطاقة: 220-240 فولت 50/60 هرتز	سرعة الهواء: 400 كم/ساعة	الأبعاد: 164 × 297 × 574 مم
طاقة الإدخال: 1800 وات (الحد الأقصى)	تدفق الهواء: 90 م <sup>3</sup> /ساعة	الوزن: 5,8 كجم
العزل الكهربائي: الفئة الثانية	مستوى الصوت: 77 ديسيبل (2 م)	الحد الأقصى لوقت التشغيل المستمر: T = 25 ثانية
درجة الحماية: IPX4	درجة حرارة الهواء (10 سم): 44 درجة مئوية	
المحرك: شفرة الضغط العالي العالمية	سرعة المروحة: 33.000 دورة في الدقيقة	
طاقة المحرك: 1200 واط		


## المكونات الرئيسية

- الغطاء الأمامي وشبكات الإدخال الجانبية المصنوعة من مادة بلاستيكية حرارية ABS بسُمك 3 مم.
- مستشعرات الأشعة تحت الحمراء للكشف عن اليدين توجد على جانبي مخرج الهواء في مجفف اليدين.
- فتحات مستطيلة متعددة لخروج هواء عالي السرعة بتوزيع متماثل على جانبي المجفف.
- شاشة علوية لعرض معلومات الحالة في الجزء العلوي، وشريط إضاءة كتنبيه بصري في حال امتلاء خزان المياه.
- الأجزاء الداخلية الرئيسية (لوحة القاعدة والمحرك ومبيد البخار) مصنوعة من مواد بلاستيكية حرارية شديدة المتانة.
- خزان مياه من البلاستيك، سهل الإزالة والتنظيف.
- محرك عالمي عالي السرعة مزود بحماية فصل حراري.
- عنصر تسخين مزود بحماية حرارية.
- فلتر الهواء HEPA H13 (وحدتان، واحدة لكل عنصر من عناصر مدخل الهواء).
- مصباح الأشعة فوق البنفسجية-سي (UVC) لتعقيم الهواء.
- لوحة إلكترونية ذكية تعمل على إيقاف تشغيل عنصر التسخين في البيئات الدافئة (عندما تزيد درجة حرارة الغرفة عن 25 درجة مئوية).



يعمل مجفف اليدين عن طريق تقريب يدي المستخدم من منطقة الاستشعار. توجد مستشعرات الأشعة تحت الحمراء على جانبي فتحات إخراج الهواء. لتجفيف اليدين، يوصى بشطف اليدين جيدًا، وإزالة أي صابون وماء متبقي. الحد الأقصى لوقت التشغيل المستمر هو  $Tsh = 25$  ثانية. بعد مرور هذا الوقت، يجب إبعاد اليدين عن المجفف ثم تقريبهما منه مرة أخرى لبدء مرة تجفيف جديدة.

يُؤدِّد مجفف اليدين تيار هواء عالي السرعة يعمل على تجفيف اليدين بسرعة. توجد لوحة عرض معلومات الحالة في الجزء العلوي وتعرض أهم معلمات التشغيل كما يلي:



- وضع الاستعداد – درجة الإضاءة المنخفضة
- وضع التشغيل – درجة الإضاءة العالية
- ممثلي بالماء

هذا الجهاز غير مخصص للاستخدام من قبل الذين يعانون من ضعف القدرات البدنية أو الحسية أو العقلية (بما في ذلك الأطفال الذين تقل أعمارهم عن 8 سنوات)، أو الذين يفتقرون إلى الخبرة والمعرفة، ما لم يتم الإشراف عليهم من قبل شخص مسؤول يعرف كيفية استخدامه وتم تحذيره من مخاطر السلامة المحتملة.

من الضروري التأكد من عدم عبث الأطفال بالمجفف والإشراف عليهم.

يجب أن يقوم فني معتمد بإجراء التوصيل بمصدر التيار الرئيسي، وكذلك الإعدادات الداخلية مثل تنظيم سرعة المحرك وفصل عنصر التسخين ونطاق الاكتشاف


فيما يلي الخطوات الواجب اتباعها لتثبيت الجهاز على الحائط

#### تحديد الموضع

- ضع قالب التثبيت المرفق على الحائط في الموضع الذي سيتم فيه تركيب مجفف اليدين.
- الارتفاعات الموصى بها موضحة في الشكل 1 لكن قد يلزم تعديل الارتفاع وفقاً لكل عملية تركيب على حدة.
- تأكد من أن الكابل الكهربائي طويل بما يكفي لإجراء التوصيل اللازم بلوحة القاعدة.
- حدّد مواضع فتحات التثبيت لتركيب الوحدة.

#### كثيفة التثبيت والوحدة


- تأكد من أن العلامات والمستوى في الموضع الصحيح، ثم احفر الثقوب لكثيفة التثبيت.
- أحكم تثبيت كثيفة التثبيت بالحائط.
- قم بتعليق الوحدة على لوحة التثبيت المثبتة وفقاً للشكل 2، ثم ثبت الوحدة على الحائط من خلال الفتحتين الموجودتين في الجزء السفلي من الوحدة كما هو موضح في الشكل.



ملاحظة: يجب تثبيت المجفف على قاعدة متينة ومغلقة

## الارتفاعات الموصى بها

من المقترح تركيب الجهاز على ارتفاع يتيح سهولة الوصول والاستخدام



## الصيانة

## صيانة فلتر HEPA


إذا لم يتم تنظيف فلتر HEPA أو استبداله في الوقت المناسب، فقد يؤدي ذلك إلى قطع تدفق الهواء وتسخين المحرك بشكل مفرط.

أزل البراغي المقاوم للعبث من الوحدة وفقاً للتسلسل الموضح في الشكل 4.

انفض الغبار عن فلتر HEPA.

يجب استبدال فلتر HEPA مرة كل 3 أشهر.

أعد تثبيت البراغي المقاوم للعبث مرة أخرى في اللوحة.




## صيانة أنبوب التصريف

أزل البراغي المقاوم للعبث من الوحدة.

قم بفك المشبك وإزالة أنبوب التصريف وتنظيف الأنبوب.

أعد إدخال أنبوب التصريف واربط المشبك مرة أخرى بالوضع الأصلي.

أعد تثبيت البراغي المقاوم للعبث مرة أخرى في اللوحة.





## صيانة خزان التصريف

أزل خزان التصريف كما هو موضح في الشكل 3.

قم بإزالة الغطاء الشفاف وتفريغ المياه من خزان التصريف. اغسل خزان التصريف بالماء النظيف.

قم بمسح خزان التصريف وتغطيته بالغطاء الشفاف قبل تركيب خزان التصريف في موضعه الأصلي.



## التنظيف

يُوصى بتنظيف المجفف بانتظام، وتجنب تراكم الغبار تدريجياً داخله، ما قد يؤدي إلى تلف المكونات الداخلية أو تقليل أداء الجهاز.

يجب تنظيفه كل 3 أشهر على الأقل.

قبل تنظيف الأجزاء الداخلية للجهاز، يجب فصل الطاقة عن مصادر الطاقة الرئيسية.

## SAFETY INSTRUCTIONS

**Before to carry on any operation, please read carefully and take into account the following instructions.**

- Only a qualified technician can install, adjust and maintain this device.
- Be careful when removing the plastic frontal cover since active and live parts of the device become accessible so there is a potential risk of electric shock.
- Before any electrical manipulation, the electrical supply from mains must be cut.
- Means for disconnection, with contact separations at least 3 mm (0.12"), must be incorporated in the fixing wiring involving all poles, in accordance with wiring rules.
- The appliances typed GW01 16 01 00 and GW01 16 01 04 are Class II insulation electrical devices, so they do not need to be earthed.

**CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

This appliance is not intended for use by persons (including children aged less than 8 years old) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Children shall not play with the appliance.

Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

During the installation process, the protection areas should be considered according to Standard VDE 0100.

Cleaning and user maintenance shall not be made by children without supervision.

## INTRODUCTION

The 'Genwec Condor' model is an efficient, compact and innovatively designed hand dryer whose structure (base plate), internal ducts and frontal cover are made of high quality thermoplastic materials, with two possible finishes according to the following codes:

- White ABS frontal cover (GW01 16 01 00)
- Silver ABS frontal cover (GW01 16 01 04)

The units of this dryer are Class II appliances based on their electrical insulation and do not need to be connected to the earthing terminal of the building, since they are double insulation devices.

The hand dryer is operated automatically by incorporating infrared sensors at both sides that activate the motor and the heater when the user's hands enter.

Drying process is based on the emission of high-speed homogeneous air sheets which are delivered from rectangular slots located on both sides of the dryer.

أولاً، يجب إزالة الغطاء للوصول إلى الأجزاء الداخلية.

يجب تنظيف الغطاء الأمامي البلاستيكي وجميع الأجزاء الخارجية باستخدام قطعة قماش ناعمة مبللة بمحلول صابون ثم تجفيفه بقطعة قماش ناعمة وجافة.

يجب تنظيف أجزاء مدخل الهواء ومخارج الهواء بطريقة مماثلة، مع التأكد من خلو الفتحات من الغبار والمواد التي قد تعيق عملية شفط الجهاز.

يجب تنظيف شاشة عرض المعلومات العلوية وواقيات أو أغطية المستشعر بقطعة قماش ناعمة، مبللة قليلاً بالماء والصابون ثم تجفيفه.

يجب إزالة بقايا الغبار داخل الجهاز بعناية باستخدام فرشاة ناعمة، مع توخي الحذر الشديد لضمان خلو منطقة دخول الهواء داخل المحرك تمامًا من الأوساخ.

يجب استبدال فلتر الهواء بانتظام، كما هو موضح في القسم المقابل من هذا الدليل.

يجب منع تسرب أو دخول الماء إلى داخل الجهاز.

## استكشاف الأعطال وإصلاحها

ملاحظة: يجب إيقاف تشغيل الطاقة قبل استكشاف الأعطال وإصلاحها

المشكلة	الإجراء
عدم بدء تشغيل مجفف اليدين	تحقق من أن الوحدة موصلة بمصدر الطاقة الصحيح وأنها قيد التشغيل
يتم تشغيل مجفف اليدين وإيقاف تشغيله بشكل غير منظم.	تحقق من نظافة عدسات المستشعر
أحياناً يفصل مجفف اليدين عند الاستخدام، ولكنه يستأنف التشغيل بعد فترة من الوقت	تحقق من نظافة مدخل الهواء في القاعدة وخلوه من الغبار. إذا كان مدخل الهواء مُغبراً، فعليك إزالة الغبار باستخدام قطعة قماش جافة أو مكنسة كهربائية

لا يجوز التخلص من المنتج في نهاية عمره الافتراضي ضمن النفايات البلدية. بل يجب أن يتم نقله إلى نقطة تجميع نفايات، تحددها السلطة المختصة أو الموردون المتخصصون في هذه الخدمة. إن إعادة تدوير منتج كهربائي أو إلكتروني بطريقة مناسبة يؤدي إلى تجنب العواقب السلبية على البيئة والصحة الناتجة عن إعادة التدوير غير الصحيحة ويسمح بإعادة تدوير المواد الخام التي يتكون منها المنتج، وهو ما يحافظ على الموارد الطبيعية ويوفر الطاقة. كذكير بضرورة إعادة تدوير المنتجات الكهربائية والإلكترونية بشكل صحيح، تم تمييز المنتج برمز حاوية مشطوبة.



يجب تركيب مجفف الشعر هذا بعيداً عن أحواض أو مرشحات الاستحمام.



## INTRODUCTION

The low noise level and limited energy consumption make these models efficient and ecological dryers. More specifically, the heating element is automatically deactivated if the room temperature is higher than  $T_{room} > 25^{\circ}\text{C}$ , with consequent energy savings.

The air inlets are located vertically on both sides of the appliance.


The hand dryer incorporates disinfection and hygiene elements such as the HEPA filter and UV-C light.

The residual water from each drying service is collected in a removable water tank which is located at the bottom of the apparatus.

Also, the dryer has an informative display located at the top and there is a strip of light LED's at the bottom indicating operating status and full water tank.

As summary, the most relevant technical features of this family of dryers are:

- Fast and efficient drying based on multiple air outlets
- Low energy consumption
- Quick and easy installation mode
- HEPA filter and UV-C light for disinfection of air supplied
- Maximum continuous running time  $T_{sh} = 25\text{ s}$
- Status information panel and visual/audible 'full tank' alarm
- Automatic disconnection of heating element in case of room temperature  $T_{room} > 25^{\circ}\text{C}$
- Robust and high quality plastic materials




## MAIN TECHNICAL CHARACTERISTICS

Electrical specifications	Fluidic specifications	Mechanical specifications
Power supply: 220-240 V 50/60 Hz	Air speed: 400 Km/h	Dimensions: 574 x 297 x 164 mm
Input power: 1800 W (maximum)	Airflow: 90 m <sup>3</sup> /h	Weight: 5,8 Kg
Electrical insulation: Class II	Sound level: 77 dBA (2 m)	Max continuous running time: T = 25 s
Protection grade: IPX4	Air temperature(10 cm): 44 °C	
Motor: Universal high pressure blade	Fan speed: 33.000 rpm	
Motor power: 1200 W		

## MAIN COMPONENTS

- Frontal cover and lateral inlet grids which are made of 3 mm thick ABS thermoplastic material.
- IR sensors for hands detection which are located at both sides of outlet air side of hand dryer.
- Multiple rectangular slots of outgoing high speed air in a symmetrical arrangement on both sides of the dryer.
- Status information upper display on top side and light strip as visual alarm in case the water tank is full.
- Main internal parts (base plate, motor and heater housing) made of strong thermoplastic materials.
- Plastic water tank, easy to remove and easy to clean.
- High speed universal motor with thermal cut-out protection.
- Heating element, thermally protected.
- HEPA H13 air Filter (two units, one for each air inlet item).
- UV-C light for air disinfection.
- Smart electronic board that makes the heating element turn off in case of warm environment ( $T_{room} > 25^{\circ}\text{C}$ ).



## HOW TO USE


The hand dryer operates by introducing user's hands into the sensing area. IR sensors are located on both sides of air output slots.

To dry hands, it is recommended rinsing both hands well, removing any soap and residual water.

The maximum continuous operating time is  $T_{sh} = 25$  seconds. After this time has passed, the hands must be removed and inserted again to start a new drying service.

The hand dryer generates a high velocity blade of air that wipes hands dry.

A status information panel is located on top and shows the operation main parameter as follows:



- Standby' mode – Low light tone
- Operating mode – High light tone
- Water full

This appliance is not intended for use by individuals with reduced physical, sensory or mental capabilities (including children under the age of 8) or with lack of experience or knowledge, unless they do so under the supervision of a responsible person who knows how to use it and having been warned of the possible safety risks.

It is necessary to ensure that children do not play with the dryer and are supervised.

## INSTALLATION

Conexion to the mains, as well as internal settings such as regulating motor speed, disconnection of the heating element and the detection range, must be carried out by an authorised technician



The following are the steps to be followed for wall installation of the appliance

### Positioning

- Position the mounting template provided on the wall where the hand dryer is to be situated.
- Recommended heights are shown in Fig 1 but height may need to be adjusted for each individual installation.
- Ensure that the electrical cable is long enough to make the necessary connection to the base plate.
- Mark the mounting holes for installing the unit.

### Mounting bracket and unit

- Ensure that marks and level are in the correct location, then drill holes for the mounting bracket.
- Securely fasten the mounting bracket to the wall.
- Hang the unit on the secured mounting plate according to Fig 2 and then fasten the unit to the wall through the 2 holes in the lower section of the unit illustrated in Figure.




NOTE: The dryer must be installed on a compact, enclosed surface

## INSTALLATION

### Recommended heights

It is suggested to install the appliance at a height that enables convenient access and use



## MAINTENANCE

### Hepa filter maintenance


If the HEPA filter is not cleaned or replaced in time, it may interrupt airflow and overheat the motor.

Remove the tamper proof screws from the unit in the sequence illustrated in Fig4.

Flick the dust off the HEPA Filter.

The HEPA Filter must be replaced every 3 months.

Install the tamper proof screws back into the panel.




### Drainpipe maintenance

Remove the tamper proof screws from the unit.

Loose clamp and remove the drain pipe and clean the pipe.

Reinsert the drain pipe and clip the clamp back to the original position.

Install the tamper proof screws back into the panel.





### Drain tank maintenance

Remove the Drain tank as shown in the Figure 3.

Remove the transparent lid and empty the water from the Drain tank. Wash the Drain tank with clean water.

Wipe the Drain tank and cover with the transparent lid before installing the Drain tank in its original position.



## CLEANING

It is recommended to clean the dryer regularly, avoiding the progressive accumulation of dust inside which can damage the internal components or reduce performance of the appliance.

It should be cleaned at least every 3 months.

To clean the internal parts of the appliance, the power must be disconnected from mains.

First, the casing must be removed to access the internal parts.

The plastic frontal cover and all external parts should be cleaned using a soft cloth dampened with a soap solution. Then dry it with a soft, dry cloth.

The air inlet parts and outlets must be cleaned in a similar way, ensuring that the slots are free of dust and matter that may hinder the appliance's suction.

The upper information display and the sensor shields or screens should be cleaned with a soft cloth, slightly dampened with soap and water. Then dry it.

Dust residue inside the appliance should be carefully removed with a soft-bristled brush, taking special care to ensure that the air access area inside the motor is completely free of dirt.

The air filter should be replaced regularly, as indicated in the corresponding section of this manual.

Prevent the water from flowing or spilling into the interiors of machine.

## TROUBLESHOOTING

NOTE: Turn off power before troubleshooting

Problem	Action
The hand dryer fails to start	Check to make sure the unit is connected to correct power supply, and that it is turned on
The hand dryer is turning on and off erratically.	Check sensor lenses are clean
The hand dryer sometimes cuts out when in use, but resumes operation after a period of time	Check the air inlet at the base is clean and free of dust. If the air inlet is dusty, simply remove dust with dry cloth or vacuum cleaner



At the end of its useful life, the product cannot be disposed of as urban waste. It must be taken to a waste collection point, established by the competent authority or by suppliers specialized in this service. Recycling an electrical or electronic product in an adequate way avoids the negative consequences for the environment and for health derived from incorrect recycling and allows the raw materials that constitute it to be recycled, saving on natural resources and energy. As a reminder of the need to recycle electrical and electronic products properly, the product is marked with a crossed out container.



This hair dryer must be fixed out of reach of a person taking a bath or shower.



Av. Joan Carles I, 46-48  
08908 L' Hospitalet de Llobregat - Barcelona - (SPAIN)  
[www.genwec.com](http://www.genwec.com)

